

- 4/29/87 PU & TIH w/2-5/16" blade bit & 1.90 tbg. Tag TOC @ 400' from surface, break circulation, drill out cement to 601'. Pressure test squeeze to 500 psig, held ok. TIH w/tbg & drill out 35' cement plug & wash sand off of RBP, POOH. SDON.
- 4/30/87 Retrieve RBP, PU & TIH w/2-1/2" Baker pkr & 1.90 tbg, circulate pkr fluid into tbg/csg annulus, set pkr @ 3500', remove BOP, flange up wellhead, place well on injection.
- 5/14/87 Mr. R.A. Saddler w/NMOCD to witness mechanical integrity test.