

DISTRICT I

1625 N. French Dr., Hobbs, NM 88240

DISTRICT II

811 South First, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

DISTRICT IV

1220 South St. Francis Dr., Santa Fe, NM 87505

OIL CONSERVATION DIVISION
1220 South St. Francis Drive
Santa Fe, NM 87505

WELL API NO. 30-025-10583
5. Indicate Type of Lease <input type="checkbox"/> STATE <input checked="" type="checkbox"/> FEE
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Skelly Penrose A Unit
8. Well No. 2
9. Pool name or Wildcat Langlie-Mattix; 7Rivers-Queen-Grayburg

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
☐ OIL WELL ☐ GAS WELL ☒ OTHER Injection Well

2. Name of Operator
Apache Corporation

3. Address of Operator
2000 Post Oak Blvd., Ste. 100, Houston, Texas 77056-4400

4. Well Location
Unit Letter L : 1980 Feet From The South Line and 660 Feet From The West Line
Section 34 Township 22S Range 37E NMPM Lea County

10. Elevation (Show whether DP, RKB, RT, GR, etc.)
3321' GR

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Perform Remedial Work | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Remedial Work | <input type="checkbox"/> Altering Casing |
| <input type="checkbox"/> Temporarily Abandon | <input type="checkbox"/> Change Plans | <input type="checkbox"/> Commence Drilling Operations | <input type="checkbox"/> Plug and Abandonment |
| <input type="checkbox"/> Pull or Alter Casing | | <input type="checkbox"/> Casing Test and Cement Job | |
| <input type="checkbox"/> Other | | <input type="checkbox"/> Other | |

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

CIBP was installed @ 3337' (above the liner top) on 10/18/00 with the approval of Gary Wink - NM/OCD to shut off water flow.

- 1.) Spot 35' cement cap on CIBP @ 3337' w/ 10 sx cement
- 2.) Spot cement plug 2374' - 2474' w/ 55 sx
- 3.) Perforate 7" casing @ 1350'. Set cement retainer @ 1320'. Cement squeeze behind 7" casing w/ 300 sx circulating to surface. Top cement retainer w/ 100 sx. Tag top of plug @ +/- 1130'.
- 5.) Spot cement plug @ 150' to surface w/ 75 sx.
- 6.) Install P&A marker.

THE COMMISSION MUST BE PROVIDED 30 HOURS PRIOR TO THE DATE OF THE PROPOSED OPERATION.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Debra J. Anderson TITLE Sr. Engineering Technician DATE 2/14/01

TYPE OR PRINT NAME Debra J. Anderson TELEPHONE NO. 713-296-6338

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

IC

FEB 20 2001

