State of New Mexico

Office	gy, Minerals and	i Natural Resouces			
DISTRICT I				.	FORM C-103
1625 N. French Dr., Hobbs, NM 8				Revised	March 25, 1999
DISTRICT II	OIL CONSERVATION DIVISION		WELL API NO.		
811 South First, Artesia, NM 8821	sia, NM 88210 2040 South Pacheco		30-025-105	584	}
DISTRICT III Santa Fe, NM 87505			Indicate Type of Lease		
1000 Rio Biazos Rd., Aztec, NM 87410				STATE	 FEE
DISTRICT IV			6. State Oil & Gas Lease No		
2040 South Pacheco, Santa Fe, NM 87505					
SUNDRY NOTICES AND REPORTS ON WELLS					
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			 Lease Name or Unit Agr 	eement Name	
DIFFERENT RESERVO	R. USE "APPLICATION FOR PERMIT" (FORM C	-101) FOR SUCH			
PROPOSALS.)			Skell	ly Penrose 'A'	Unit
1. Type of Well:					
✓ OIL WELL GAS WELL OTHER					
			8. Well No.		
			o. Well No.	11	
Apache Corporation			9. Pool name or Wildcat		
5. Addition of Operator			Langlie-Mattix; 7 Rvrs-Q-Grayburg (37240)		
2000 Post Oak Blvd., Ste. 100, Houston, Texas 77056-4400				7 KVIS-Q-GI2	lybuig (37240)
i	M + 660 p.m. Court	h Line and 660	Feet From The W	est Line	
Unit Letter	M: 660 Feet From The Sout	h Line and 660		est Line	
Section	34 Township 23S Range	37E NMPM	Lea co	ounty	
	10. Elevation (Show whether DI	, RKB, RT, GR, etc.)	*		
	3326' GR				
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data					
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:					
MOTICE OF BATEATION TO. SUBSEQUENT REPORT OF:					
Derform Demedia	Work Plug and Abandon	Remedial Work	Г	Altering Casin	n
Perform Remedial Work Plug and Abandon Remedial Work			<u></u>	_ Artering cashing	9
☐ Temporarily Abandon ☐ Change Plans ☐ Commence Drilli			ing Operations	Plug and Aban	donment
Pull or Alter Casing Casing Test and C			Cement Job		
Other		Other			
12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.					
8/25/00	MIRU. Nipple down wellhead. Nipple up BOP. Run in hole w/ coiled tubing to 3350'. Spot 50 sx Class "C" cement w/ 2% CaCl @ 3350' - 3008'. Pull out of hole & wait on cement 4 hours. Dig out cellar - found hole in casing. Install 7" clamp on casing. Run in hole w/ coiled tubing & tag top of cement @ 3015'. Pull up hole to 3000'. Circulate 60 bbls mud laden fluid. Pull out of hole w/ coiled tubing.				
8/26/00	Rig up wireline. Run in hole & perforate @ 1225'. Pull out of hole. Rig down wireline. Run in hole w/ cement retainer & set @ 1150'. Squeeze behind 7" casing w/ 300 sx - no circulation. Pressure up to 1200#. Sting out of retainer. Capped retainer w/ 25 sx cement @ 1150' - 850'. Pull out of hole. Wait on cement 2 hours. Tagged top of cement @ 853'. Pull up hole to 250'. Perf 4 holes @ 250'. Pull out of hole & rig down wireline. Pump down casing & break circulation. Squeeze w/ 125 sx Class "C" cement. Circulate to surface inside & outside 7" casing. Install P&A marker.				
Thereby certify that the information above is true and complete to the best of my knowledge and belief. SIGNATURE TITLE Sr. Engineering Technician DATE 9/25/00 TYPE OR PRINT NAME Debra J. Anderson TELEPHONE NO. 713-296-6338					
(This space for State (se)		1.0			