

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER - Water Well	7. Unit Agreement Name _____
2. Name of Operator Skelly Oil Company	8. Farm or Lease Name H. O. Sims
3. Address of Operator P. O. Box 1351, Midland, Texas 79701	9. Well No. 16
4. Location of Well UNIT LETTER M , 660 FEET FROM THE South LINE AND 510 FEET FROM THE West LINE, SECTION 34 TOWNSHIP 22S RANGE 37E NMPM.	10. Field and Pool, or Wildcat _____
15. Elevation (Show whether DF, RT, GR, etc.) 3335' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Replug and abandon <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER _____ <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was plugged and abandoned September 16, 1967. Due to waterflows into non-unitized intervals, the New Mexico Oil Conservation Commission has requested that this well be replugged to meet current standards.

- 1) Move in workover rig.
- 2) Drill out cement and clean out to 3310'.
- 3) Spot 200 sacks Class "C" cement, 2% CaCl, 2600-2800'.
- 4) Perforate 8-5/8" OD casing with two 0.45" diameter holes at 1100'.
- 5) Spot 250 gallons 15% N.E. acid over perms. at 1100'.
- 6) Cement squeeze perms. with 200 sacks Class "C" cement, 2% CaCl.
- 7) Spot 20 sack cement plug to surface.
- 8) Set dry hole marker.

NOTE: All intervals not cemented will be filled with 10.2# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. R. Crow TITLE Lead Clerk DATE 1-8-75

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 1 1975

OIL CONSERVATION COMM.
HOBBS, N. M.