

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-032104

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

-

7. UNIT AGREEMENT NAME

-

8. FARM OR LEASE NAME

A.H. Blinebry Fed. NCT-1

9. WELL NO.

7

10. FIELD AND POOL, OR WILDCAT

Blinebry (Oil)
Tubb (Gas)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 19, T-22-S, R-38-E

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3370' (GR)

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

PULL OR ALTER CASING

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

<input checked="" type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rigged up. Install BOP. Pull tbgs. & pkr.
2. Clean out to 6260'.
3. Set RBP @ 6050' & pkr. @ 5079'. Test csg between Blinebry & Tubb zones w/1000#. Tested OK.
4. Set CIBP @ 6060' & dump 7 sx cement on plug. PBD 6025'. Tubb zone abandoned 2-20-78.
5. Install rods & pump. Test well. Pull rods & pump. Install BOP.
6. Set pkr. @ 5463'. Acidize perforations 5558-5688' w/7500 gal. 15% Xylene in 5 equal stages using 500# salt & 100# acid flakes between stages. Flush w/35 bbls 2% KCl water.
7. Install pumping equipment.
8. On 24 hr. potential test ending 3-16-78, Blinebry zone pumped 12 bbl. oil, 13 bbl. wtr, & GOR - 3083.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

Asst. Dist. Supt.

DATE

3-23-78

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

ACCEPTED FOR RECORD

DATE

MAR 30 1978

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

*See Instructions on Reverse Side

[REDACTED]

AIR 2 - 107

OIL COMBUSTION COMML
HOBBS, N. M.