

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division

J. Box 1980

Hobbs, NM 88241

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Texaco Exploration & Production Inc.

3. Address and Telephone No.

P. O. Box 3109, Midland, TX 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit Letter D, Section 20, Township 22^S, Range 38E
660' From North Line & 660' From The West Line

5. Lease Designation and Serial No.

LC 032104

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Unit D

8. Well Name and No.

Blinebay A.H.
Federal NCT-1 #10

9. API Well No.

30-02512142

10. Field and Pool, or Exploratory Area

Brunson San Andres, East

11. County or Parish, State

Lea, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Notify BLM of intent to plug & abandon well. (note the well is currently T & A W/CIBP)
- 2) MIRU, Nipple up B.O.P.
- 3) TIH W/workstring to @ 4000', Tag CIBP, Circ. well bore W/salt gel mud 25# per bbl.
- 4) Spot 25 sx cement, Plug @ 4000-3900
- 5) Cut 5 1/2 csg. @ 2931' & lay down same
- 6) Spot 100 sx cement, plug from 2981-2831 (Stub & 8-5/8" casing shoe plug)
- 7) Spot 45 sx cement, plug from 450-350 (13-3/8" shoe plug)
- 8) Perf. 8-5/8" csg. @ 200' & circ. cement to surface behind 8-5/8" csg. @ 200 sx cement, leave 8-5/8" csg. full of cement from 200' to surface
- 9) Cut off wellhead & cap well & install dry hole marker; clean location & move off

14. I hereby certify that the foregoing is true and correct

Signed David Deax Title Reservoir Engineer

Date 3/12/97

(This space for Federal or State office use)

Approved by DAVID R. GLASS

Title UNITED STATES ENGINEER

Date MAR 23 1997

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

*See Instruction on Reverse Side