

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

LC-032104

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
2. NAME OF OPERATOR		7. UNIT AGREEMENT NAME	
3. ADDRESS OF OPERATOR		8. FARM OR LEASE NAME	
TEXACO Inc.		A.H. Blinebry Fed. NCT-2	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface Well is located 660' FSL & 660' FWL of Section 29, T-22-S, R-38-E, Unit Letter 'M', Lea County, New Mexico		9. WELL NO.	
14. PERMIT NO.		10. FIELD AND POOL, OR WILDCAT	
Regular		Blinebry Gas	
15. ELEVATIONS (Show whether DF, RT, GR, etc.)		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA	
3390' (DF)		Sec. 29, T-22-S, R-38-E	
12. COUNTY OR PARISH		13. STATE	
Lea		New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

(Other) Complete in Drinkard

☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up & install BOP. Pull 2 1/16" production tubing.
2. Drill out Bridge Plug. Plug @ 6392'.
3. Log Well for perforation intervals. Perforate 5 1/2" OD csg. in Drinkard.
4. Acidize Drinkard perforations w/3000 gal. 15% NE Acid.
5. Frac Drinkard perforations w/30,000 gal. Polymer Gel in 4-equal stages using rock salt & Benzoic Acid.
6. Install pumping equipment. Test Drinkard & place on production.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Asst. Dist. Supt. DATE 6-21-76

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

APPROVED

JUN 24 1976

BERNARD MOROZ
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side