

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

5. LEASE
LC-032104

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
--

7. UNIT AGREEMENT NAME
--

8. FARM OR LEASE NAME
A. H. Blinebry

9. WELL NO.
25

10. FIELD OR WILDCAT NAME
Tubb & Drinkard

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 28, T-22-S, R-38-E

12. COUNTY OR PARISH
Lea

13. STATE
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3373' (DF)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

1. oil well ☒ gas well ☐ other

2. NAME OF OPERATOR

Texaco, Inc.

3. ADDRESS OF OPERATOR

P. O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

AT SURFACE:

AT TOP PROD. INTERVAL: 1650' FML & 660' FSL

AT TOTAL DEPTH: (Unit Letter 'N')

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☒

REPAIR WELL ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

CHANGE ZONES ☐

ABANDON* ☐

(other) ☐

SUBSEQUENT REPORT OF:

☐

☐

☐

☐

☐

☐

☐

☐

☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- Rig up. Pull rods & pump from Drinkard string. Clean out both 2 7/8" Csq. strings.
- Reset Drinkard packer @ 6800'. Acidize Drinkard perfs. 6870'-7223' w/1500 gals. 15% NEFE LST Acid in 3-stages using 100# rock salt & Benzoic Acid Flakes between stages.
- Reset pkr. @ 6830'.
- Set RBP in Tubbs string @ 6587' & pkr @ 6500'. Acidize commingle perfs. 6557'-6562' w/50 gals. 15% NEFE LST Acid. Reset RBP @ 6500' & pkr. @ 6200'.
- Acidize Tubb perfs 6298'-6406' w/1000 gals. 15% NEFE LST Acid in 2 stages using 50# rock salt & 50# Benzoic Acid Flakes between stages. Flush w/2% KCl water. Pull pkr & RBP.
- Pull RBP from Drinkard.
- Install production equipment. Test & place on production.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED _____ TITLE Asst. Dist. Supt. DATE 1/9/81

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APPROVED

JAN 14 1981

DISTRICT SUPERVISOR