

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well gas ☐ well other ☐
2. NAME OF OPERATOR
TEXACO Inc.
3. ADDRESS OF OPERATOR
P. O. Box 728, Hobbs, New Mexico 88240
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 660' FNL & 660' FWL
AT TOP PROD. INTERVAL: (Unit Letter 'D')
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input checked="" type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>		<input type="checkbox"/>
(other)			

5. LEASE
LC-032104
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
-
7. UNIT AGREEMENT NAME
-
8. FARM OR LEASE NAME
A. H. Blinebry Fed. NCT-1
9. WELL NO.
33
10. FIELD OR WILDCAT NAME
Drinkard & Tubb
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 28, T-22-S, R-38-E
12. COUNTY OR PARISH
Lea
13. STATE
New Mexico
14. API NO.
-
15. ELEVATIONS (SHOW DF, KDB, AND WD)
3374' (DF)

(NOTE: Report results of multiple completion or zone change on Form 9-331.)

RECEIVED

AUG 25 1980

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rigged up. Install BOP. Pull rods & pump from Drinkard.
2. Clean out Drinkard. Clean out Tubb.
3. Set pkr. @ 6238' in Tubb Zone. Acidize perfs. 6350'-6420' w/2000 gal. gelled 2% KCL water & 2000 gal. 20% NEFE Acid in 2-stages using 500# rock salt between stages. Pull pkr.
4. Set pkr. @ 6844' in Drinkard Zone. Acidize perfs. 7044'-7311' w/2000 gal. 20% NEFE Acid in 2-stages using 500# rock salt between stages.
5. Install pumping equipment. On 24 Hr. PT, ending 8-20-80, well pumped 11 BO & 17 BW, GOR 6727.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED J. A. Schuff TITLE Asst. Dist. Supt. DATE 8-21-80

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

ACCEPTED FOR RECORD

AUG 28 1980

U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO