Form 1900 DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT Budget Bureau No. 1004-0135 Expire: March 31, 1903 SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or resentry to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals I. If Unit or CA, Agreement Designation Unit Letter M I. Type of Well Gas 0 I. If Unit or CA, Agreement Designation I. Type of Well Gas 0 Blinebry A H Fed NCT-1 #33 2. Name of Operator Blinebry A H Fed NCT-1 #33 3. Address and Telephone No. 30-025-21666 P. O. Box 3109 – Midland, TX 79701 I. Field and Pool, or Exploratory Area 4. Location of Well (Footge, Sec., T., R., M., or Survey Description) Brunson Drinkard 11. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF SUBMISSION TYPE OF ACTION Image: Abandoancent Recompletion Image: Final Abandoancent Recompletion Image: Final Abandoancent Report Plugging Back Image: Final Abandoancent Report Plugging Back Image: Final Abandoancent Report Plugging Back			N.M. OIL CONS. COMMISSION P.O. BOX 1980 HOBBS NEW MEXICO 88240
L 0.92104 L 1.10 Latter M <	(June 1990) DEPARTMENT	OF THE INTERIOR	Budget Bureau No. 1004-0135 Expires: March 31, 1993
Do not use this form for proposals to drill or to deepen or rearry to a different reservoir. In the number of			I I I I I I I I I I I I I I I I I I I
SUBMININT INTROPLICATE Subminint in TROPLICATE Interest of Operator Interest of Operat	Do not use this form for proposals to drill	or to deepen or reentry to a different reserv	
2. None of Operator Potaco BAP, Inc.		··· 1	8. Well Name and No.
P. 0. Box 3109 - Midland, TX 79701 Double of Long TX 79701 Location of Wall (Fooseg: Sec. T. R. M. or Survey Description) Location of Wall (Fooseg: Sec. T. R. M. or Survey Description) Location of Wall (Fooseg: Sec. T. R. M. or Survey Description) Location of Wall (Fooseg: Sec. T. R. M. or Survey Description) Control of Price Technology Area Brunson Drinkard Location of Wall (Fooseg: Sec. T. R. M. or Survey Description) Control of Price Technology Area Location of Wall (Fooseg: Sec. T. R. M. or Survey Description) Control of Price Technology Area Location of Mail (Fooseg: Sec. T. R. M. or Survey Description) Control of Price Technology Area Control of Interior Control of Price Technology Area Control of Price Technology Area Control of Interior Control of Price Technology Area Control of Price T		: <u>;</u>	9. API Well No.
4. Location of Well (Focage, Sec., T. R., M., or Sarvey Description) 60° FSI. 660° FWL Sec 21 T-22S R-38E 12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF SUBMISSION TYPE OF ACTION Notice of Inters Subsequence Report Distributed State Completion Observe Proposed or Completed Operations (Clearly and all periment details, and give perimeer dates, including estimated date of stating ary proposed work. If well is directionally detile details and prove perimeer dates, including estimated date of stating ary proposed work. If well is directionally detile details are and noses perimeer dates, including estimated date of stating ary proposed work. If well is directionally detile details. State of the stating ary proposed work. If well is directionally detile details. State of the stating ary proposed work. If well is directionally detile details. State of the state of the stating ary proposed work. If well is directionally detile details. State of the work of the state of the s	-		
		ription)	
CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF SUBMISSION TYPE OF SUBMISSION Abadoament Abadoament Abadoament Abadoament Abadoament Abadoament Abadoament Abadoament Abadoament Charge of Plans Abadoament Charge of Plans Abadoament Charge of Plans Abadoament Abadoament Abadoament Charge of Plans Abadoament Abadoament Charge of Plans Abadoament Abadoament Abadoament Abadoament Charge of Plans Abadoament Abadoament Charge of Plans Abadoament Charge of Plans Abadoament Abadoament Charge of Plans New Construction Charge of Plans Abadoament Charge of Plans New Construction Charge of Plans Charge of Plans New Construction Charge of Plans New Construction Charge of Plans New Construction Charge of Plans Charge of Plans New Construction Charge of Plans Notice Subcourted to completed Operations Charge of Plans Notice Subcourted to completed Operations Charge of Plans Notice Subcourted to completed Operations Charge of Plans Notify BlM of intent to plag and abandon vell. Notify BlM of intent to plag and abandon vell. Notify BlM of intent to plag and abandon vell. Notify BlM of intent to plage notions Subcourted to write intent of the gling down will			
TYPE OF SUBMISSION TYPE OF ACTION Modes of Intent Charge of Plans Subsequent Report Plugging Back Charge of Plans Subsequent Report Plugging Back Non-Routine Fracturing Final Abandonment Noice Plugging Back Non-Routine Fracturing Final Abandonment Noice Dispose Water (Coversion to Injection Other	660' FSL 660' FWL Sec 21	T-225 R-38E ,	Lea
Image: Second	12. CHECK APPROPRIATE BOX(s)	TO INDICATE NATURE OF NOTICE, RE	PORT, OR OTHER DATA
Charge of Plans Boompletion Boompletion	TYPE OF SUBMISSION	TYPE OF ACTION	
Bussequent Report Final Abandonment Notice Brind Abandonment Notice Bussequent Report Brind Abandonment Notice Bussequent Report Bussequent Report	X Notice of Intent	X Abandonment	Change of Plans
Find Abandonment Notice	Subsequent Report		
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drille complete locations and measured and true vertical deepts for all markets and zones pertinent to this work.)* 14. Notify BLM of intent to plug and abandon well. 2. MIRU. Nipple down wellhead. Nipple up BOP 3. THH w/swedge 6. 2-1/16" tubing. Swedge tight spot @ 3428". 4. TOH w/swedge. 71H w/CIBP @ 7050'. Set CIBP. Rig down wireline truck. 5. TIH w/2-1/16" tubing to 7050'. Circ. casing w/25# per bbl. salt gel mud. 6. Spot 25 sx cmt plug from 7050'. Set CIBP. Rig down wireline truck. 7. POOH to 5890'. Spot 20 sx plug from 5890' - 5350'. 8. Perf. & sqz @ 4250'. Sqz 40 sx cemt w/packer @ 3580'. WOC & tag. 10. Perf. & sqz @ 23700'. Sqz 40 sx cemt w/packer 2700'. 11. Cut and pull 2-7/8" casing @ 1700'. Spot 120 sx cmt from 1700' - 1360'. WOC & tag. 12. Spot 150 sx from 400' - surface. 13. ND BOP & cut off wellhead. Cap well & install dry hole marker. Rig down and move off. 14. I hereby certify that the foregoing is true and correct Signed MTM-MARCH 14. I hereby certify that the foregoing is true and correct Signed MTM-MARCH 15. MD BOP & cut off wellhead. Cap well & install dry hole marker. Rig down and move off. 16. MTM-MARCH Title Operations Enginee	Final Abandonment Nation		
(Note: Report Relia of multiple completion of Multiple completion and measured and true vertical depth of multiple completion and true vertical depth of multiple completion and true vertical depth of mul			
 13. Describe Proposed or Completed Operations (Clearly tate all pertinent details, including estimated date of starting any proposed work. If well is directionally drille give subsurface locations and measured and true vertical depths for all markers and zooes pertinent to this work.)* 14. Notify BLM of intent to plug and abandon well. 25. MIRU. Nipple down wellhead. Nipple up BOP 36. THH w/swedge. THH w/CIBP @ 7050'. Stort CIBP. Rig down wireline truck. 37. POOH to 5890'. Spot 20 sx plug from 7050' - 6350'. 38. Perf. & sqz @ 4250'. Sqz 40 sx cement into formation w/packer @ 4100'. WOC and tag. 39. Perf. & sqz @ 4250'. Sqz 40 sx ceme w/packer 2700'. 30. Perf. & sqz @ 2836'. Sqz. 40 sx cmt w/packer 2700'. 31. Cut and pull 2-7/8' casing @ 1700'. Spot 120 sx cmt from 1700' - 1360'. WOC & tag. 39. BOP & cut off wellhead. Cap well & install dry hole marker. Rig down and move off. 			(Note: Report results of multiple completion on Well
1. Notify BLM of intent to plug and abandon well. 2. MIRU. Nipple down wellhead. Nipple up BOP 3. TIH w/swedge & 2-1/16" tubing. Swedge tight spot @ 3428'. 4. TOH w/swedge. TIH w/CIBP @ 7050'. Set CIBP. Rig down wireline truck. 5. TIH w/2-1/16" tubing to 7050'. Circ. casing w/25# per bbl. salt gel mud. 6. Spot 25 sx cmt plug from 7050' - 6350'. 7. POOH to 5890'. Spot 20 sx plug from 5890' - 5350'. 8. Perf. & sqz @ 4250'. Sqz 40 sx cement into formation w/packer @ 4100'. WOC and tag. 9. Perf. & sqz @ 3700'. Sqz 40 sx cemt w/packer 2580'. WOC & tag. 10. Perf. & sqz @ 2700'. Sqz 40 sx cmt w/packer 2500'. 11. Cut and pull 2-7/8" casing @ 1700'. Spot 120 sx cmt from 1700' - 1360'. WOC & tag. 12. Spot 150 sx from 400' - surface. 13. .ND BOP & cut off wellhead. Cap well & install dry hole marker. Rig down and move off. Tute Operations Engineer Signed M M M M Signed for ORGING'SCD'. OEE G. LARA	 Describe Proposed or Completed Operations (Clearly state all pe give subsurface locations and measured and true vertical of 	rtinent details, and give pertinent dates, including estimated date of s	tarting any proposed work. If well is directionally drilled
14. I hereby certify that the foregoing is true and correct Signed <u>MA Junch</u> <u>Title</u> <u>Operations Engineer</u> <u>Date</u> <u>6/1/3/5.5</u> (This space for CORIG: SCD.) OE G. LARA OFTENDING INSER	 MIRU. Nipple down wellhead. Nip TIH w/swedge & 2-1/16" tubing. TOH w/swedge. TIH w/CIBP @ 7050 TOH w/swedge. TIH w/CIBP @ 7050'. Spot 25 sx cmt plug from 7050'. Spot 25 sx cmt plug from 7050'. POOH to 5890'. Spot 20 sx plug f Perf. & sqz @ 4250'. Sqz 40 sx c Perf. & sqz @ 2700'. Sqz 40 sx c Perf. & sqz @ 2836'. Sqz. 40 sx Cut and pull 2-7/8" casing @ 1700 Spot 150 sx from 400' - surface. 	pple up BOP Swedge tight spot @ 3428'. '. Set CIBP. Rig down wireline truck. Circ. casing w/25# per bbl. salt gel mud. 6350'. Erom 5890' - 5350'. Cement into formation w/packer @ 4100'. W cmt w/packer @ 3580'. WOC & tag. < cmt w/packer 2700'.)'. Spot 120 sx cmt from 1700' - 1360'. W	10C and tag.
Signed <u>RANders</u> <u>Tide</u> <u>Operations Engineer</u> <u>Date</u> <u>6/23/55</u> (This space for (ORIG. SED.)) JOE G. LARA OFTENDI EUM FRIGINEER			
Signed RANder Tide Operations Engineer Date 6/23/55			
Signed <u>RANders</u> <u>Tide</u> <u>Operations Engineer</u> <u>Date</u> <u>6/23/55</u> (This space for (ORIG. SED.)) JOE G. LARA OFTENDI EUM FRIGINEER			
Signed <u>RANders</u> <u>Tide</u> <u>Operations Engineer</u> <u>Date</u> <u>6/23/55</u> (This space for (ORIG. SED.)) JOE G. LARA OFTENDI EUM FRIGINEER		· . ·	
(This space for (ORIG: SCD.) JOE G. LARA PETERON ENM FRIGINEER	14. I hereby certify that the foregoing is true and correct		
(This space for (ORIG: SED.)) DE G. LARA DETENDIEUM ENGINEER			Date 6/22/55
Conditions of approval, if any: See attached.	(This space for CORIG: SCD.) JOE G. LAR	Tide PETROLEUM ENGINE	In -izila-
	Conditions of approval, if any: See attache	el.	Utic If all is

*See Instruction on Reverse Side



BUREAU OF LAND MANAGEMENT CARLSBAD RESOURCE AREA

Permanent Abandonment of Wells on Federal Lands

Conditions of Approval

1. <u>Approval:</u> Plugging operations shall commence within 90 days from the approval date of plugging procedure.

2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Eddy County call (505)887-6544 ; for wells in Lea County call (505) 393-3612.

3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of water. Minimum nine (9) pounds per gallon.

5. <u>Cement Requirement:</u> Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either class "C", for up to 7,500 feet of depth, mixed at 14.8 lbs./gal. with 6.3 gallons of fresh water per sack or class "H", for deeper than 7,500 feet plugs, mixed at 16.4 lbs./gal. with 4.3 gallons of fresh water per sack.

6. <u>Dry Hole Marker:</u> All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement. The following information shall be permanently inscribed on the dry hole marker: Well name and number, the name of the operator, the lease serial number, the surveyed location (the quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer; such as metes and bounds).

7. <u>Subsequent Plugging Reporting</u>: Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show <u>date</u> well was plugged.

Following the submittal and approval of the Subsequent Report of Abandonment, surface restoration conditions of approval will be developed and furnished to you.

31. J. J. 1985

a da e saide Seleta