

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-22039
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER SWD Well	7. Lease Name or Unit Agreement Name Simmons
2. Name of Operator Zia Energy, Inc.	8. Well No. 2
3. Address of Operator P.O. Box 2219, Hobbs, NM 88241	9. Pool name or Wildcat San Andres SWD
4. Well Location Unit Letter <u>G</u> : <u>2310</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>5</u> Township <u>22 South</u> Range <u>37 East</u> NMPM <u>Lea</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>3424' GR</u>	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: Re-Entry of P & A Well <input checked="" type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up Eunice Well service and Lea County Fishing tools.
2. Pull dry hole marker & drill cement to 90'.
3. Drilled cement plugs 1122' to 1347', 2115' to 2391' & 3865' to 3925'. Pressure tested casing down to 3925' with 500 psi for 10 minutes without loss of pressure.
4. Drilled CIBP at 3925'. Clean out to 4700'.
5. Set RBP at 4700'. Dumped 7 sxs of 10-20 sand on plug. Set packer at 3500'. Squeezed perfs. from 4013' - 4464' using 500 sxs of cement. Squeezed up to 3000#
6. Drilled cement from 4034' to 4470'. Tested casing to 500# for 15 minutes without loss of pressure.
7. Circulate sand off RBP and pulled BP.
8. Continued on next page.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Farris Nelson TITLE President DATE 19/02/91
TYPE OR PRINT NAME Farris Nelson TELEPHONE NO. 393-2937

(This space for State Use)

Orig. Signed by
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: