

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	<b>E-3480-1</b>

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> <b>Dual</b>	7. Unit Agreement Name
2. Name of Operator <b>Gulf Oil Corporation</b>	8. Farm or Lease Name <b>R. E. Cole (NCT-A)</b>
3. Address of Operator <b>Box 670, Hobbs, New Mexico 88240</b>	9. Well No. <b>8</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>2130</b> FEET FROM THE <b>South</b> LINE AND <b>2130</b> FEET FROM THE <b>West</b> LINE, SECTION <b>16</b> TOWNSHIP <b>22-S</b> RANGE <b>37-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Undes Montoya &amp; Silurian</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3392' GL</b>	12. County <b>Lea</b>

16.

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

#### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐

OTHER **Abandon Montoya** ☐

#### SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**7302' TD.**

Form C-103, dated 9-18-67 stated our proposed plan to repair communications. An unsuccessful attempt was made to do this work. Our plans are now to abandon the Montoya and leave as a single completion in the Silurian as follows: Pull all dual equipment. Run Baker DR plug and set in Baker Model D packer at 7240'. Pump 500 gallons of Temblock and spot from 7220' to 6917'. Displace Temblock into Silurian zone down to approximately 7160'. CI for 2 hours with pump pressure on tubing. Circulate Temblock out of casing. Retrieve DR plug. Run Halliburton EZ drill squeeze packer with sliding valve. Set packer at 7230'. Pump 30 sacks of Class H cement into casing in Montoya zone. Displace to EZ drill packer. WOC 36 hours. Run Baker Model R packer on 2-3/8" tubing and set at approximately 7220'. Test squeeze packer with 1000#, 30 minutes. Raise packer to 7150'. Swab and test and place Silurian on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY

**C. D. BORLAND**

SIGNED \_\_\_\_\_ TITLE **Area Production Manager** DATE **October 11, 1967**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: