

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

6. IF INDIAN ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., M., OR BLK. AND

SURVEY OR AREA

12. COUNTY OR PARISH

13. STATE

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Imperial American Resources Fund, Inc.

3. ADDRESS OF OPERATOR

215 Mid America Building Midland, Texas

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface660' FNL, 660' FEL, Sec. 7, T 22 S, R 38 E,
Lea County, New Mexico.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3358 GR

Lea

New Mexico

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well is inactive, it has been shut down because of non-economic production capability. Total Depth of well is 7555' w/7" csg cemented w/350 sks Class C. Cement 8% gel & 300 sks Class C cement w/2% gel 9 5/8" csg set @860' w/cement circ. We propose to plug and abandon as follows:

- 1 - Dump 35' cement on top of otis permatrive pkr set @6420' (pkr stuck in well)
- 2 - Spot 100' plug (25 sks) above Blinbry perfs from 5800' to 5700' (we may elect to set CIBP w/35' cement in place of this plug)
- 3 - Spot 100' plug (25 sks) 4300' to 4200'
- 4 - Spot 100' plug (25 sks) 2800' to 2700'
- 5 - Shoot off 7" csg. @ free point approx. 1500' to 1000'
- 6 - Spot 100' plug (35 sks) from 1500' to 1400' or at top of csg stub if above 1500'.
- 7 - Spot 100' plug (35 sks) from 800-900 across 9 5/8 csg shoe @860'
- 8 - Place 10' cement plug in top of Surface Csg.
- 9 - Erect Dry hole marker
- 10 - Hole will be loaded w/10# mud laden fluid.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE

March 23, 1973

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side