

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-7

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator <u>Anadarko Production Company</u> 3. Address of Operator <u>P.O. Box 806 Eunice, New Mexico</u> 4. Location of Well UNIT LETTER <u>D</u> <u>330</u> FEET FROM THE <u>North</u> LINE AND <u>820</u> FEET FROM THE <u>West</u> LINE, SECTION <u>14</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) <u>3348 GR</u>	7. Unit Agreement Name 8. Farm or Lease Name <u>Hugh</u> 9. Well No. <u>13</u> 10. Field and Pool, or Wildcat <u>So. Eunice San Andres</u> 12. County <u>Lea</u>
---	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RUPU. TOH w/rods, pump & tbq.
2. TIH w/6-3/4" bit & DC. CO scale to TD 4205'. TOH.
3. RU Wireline Co. Run Casing Inspection Log.
4. TIH w/RBP & PKR. Isolate hole, sand off RBP, squeeze 100 sx Class "C" cement into hole. Circ excess from hole. TOH w/PKR.
5. TIH w/bit. Drill out cement. Circ sand from RBP. TOH w/bit.
6. TIH w/PKR & latch on tool. Retrieve RBP. Isolate perfs, spot 11 bbls 15% N.E. Acid over, displace w/100 bbls 2% KCL w/scale inhibitor & corrosion chemical. SI overnight. TOH w/ RBP & PKR.
7. TIH w/production string. POP.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by: Howard E. Hackett TITLE Production Foreman DATE July 9, 1982  
ORIGINAL SIGNED BY  
APPROVED BY: JERRY SEITON TITLE \_\_\_\_\_ DATE JUL 14 1982  
CONDITIONS OF APPROVAL, IF ANY: