

NO. OF COPIES RECEIVED

DISTRIBUTION

SANTA FE

FILE

U.S.G.S.

LAND OFFICE

OPERATOR

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease

State ☐Fee ☐

5. State Oil & Gas Lease No.

NMR 457

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator TEXAS PACIFIC OIL NO. INC.		8. Farm or Lease Name Will Cary
3. Address of Operator P. O. Box 1069 - Hobbs, New Mexico 88240		9. Well No. 9
4. Location of Well UNIT LETTER E , 1650 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 22 TOWNSHIP 22 RANGE 37 NMPM.		10. Field and Pool, or Wildcat 5-11-60-11-11-37
15. Elevation (Show whether DF, RT, GR, etc.) 3364.5' GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Completion <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Clean out cement to 7267' PBTD/ Displace hole w/1% KCL water with 1 gal./1000 Marflo II.
2. Ran Gamma-Collar log. Perf. 7233-37-43-45-49'.
3. Pump 500 gal. 15% MCA in formation.
4. Swab load and test. If Lower zone productive of water:

1. Set CIBP @ 7225' and perf. 7203-06-11-15'.
2. Pump 500 gal. MCA. Run temp. survey. Swab & test.

If Lower zone is productive of oil:

1. Perf. 7203-06-11-15-23-27 & 30'. Acidize w/3000 gal. 20% CRA-35.
2. Swab load and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by

SIGNED **Sheldon Ward**TITLE **Area Superintendent**DATE **4-13-71**APPROVED BY **[Signature]**TITLE **SUPERVISOR DISTRICT**DATE **APR 15 1971**

CONDITIONS OF APPROVAL IF ANY:

RECEIVED

APR 14 1971

**OIL CONSERVATION COM.
HO300, N. M.**