

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER <input type="checkbox"/>
--	-----------------------------------	--------------------------------

6. Name of Operator	7. Unit Agreement Name
Anadarko Production Company	LMPSU

8. Farm or Lease Name	9. Well No.
Tract 13C	9

10. Field and Pool, or Whdcat
Langlie Mattix-Penrose

11. Location of Well
UNIT LETTER <u>C</u> <u>760</u> FEET FROM THE <u>North</u> LINE AND <u>2080</u> FEET FROM <u>West</u> LINE, SECTION <u>27</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.

12. County
Lea

13. Elevation (Show whether DF, RT, GR, etc.)
3330' GL

14. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPWS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

15. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. MIRUPU TOH w/ production string
2. TIH w/ RBP & PKR. Locate hole in csg.
3. Set RBP @ 100' below hole in csg. Dump 2 SX sand on top of RBP.
4. RU Cementing Co. & pump 100 SX Neat cement into hole or holes.
5. RURU Drill out cement inside 4½" csg. If squeeze job won't hold press, resqueeze. If it will hold pressure, wash sand from RBP & retrieve RBP & TOH.
6. TIH w/ production string. POP.

16. I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNED <u>Howard O. Zickel</u>	TITLE <u>Field Foreman</u>
DATE <u>April 3, 1985</u>	
ORIGINAL SIGNED BY JERRY SEXTON	
DISTRICT 1 SUPERVISOR	
APPROVED BY _____	TITLE _____
DATE <u>APR - 8 1985</u>	
CONDITIONS OF APPROVAL, IF ANY:	