

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
State

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator American Exploration Company	8. Farm or Lease Name New Mexico "M" State
3. Address of Operator 2100 RepublicBank Center, Houston, Texas 77002	9. Well No. 58
4. Location of Well UNIT LETTER N 150 FEET FROM THE South LINE AND 1360 FEET FROM THE West LINE, SECTION 20 TOWNSHIP 22S RANGE 37E NMPM.	10. Field and Pool, or Whdcat Langlie Mattix Seven RQ- 678
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

American Exploration Company proposes to plug and abandon the subject well as follows:

1. Set CIBP @ 3425' ± (top perforation @ 3482'). Dump 35' of cmt. on top of CIBP.
2. Circulate the hole with 10 ppg mud. Set a 25 sx. cement plug @ 2450'. Tag plug.
3. Pump a 75 sx. cement plug outside the 5-1/2" casing at approximately 324', leaving at least 100' inside the 5-1/2" csg.; or circulate the 5-1/2" X 8-5/8" annulus, whichever occurs first.
4. Install steel marker. Clean location.

RECEIVED
JAN 4 1989
OIL CONSERVATION DIVISION
SANTA FE, NEW MEXICO

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bill Priebe TITLE Prod. Supt. DATE 12/28/88

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

JAN 04 1989

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 3 1989

QCD
HOBBS OFFICE