

ELLIOTT B NO. 6
Acidize & Test Pump
Page 3

7. Move in and kill well w/9# brine w/1 gal Adomall/1000 gals, if necessary.
8. POOH w/rods & pump.
 - A. Install BOP.
 - B. Tag for fill w/2-7/8" tbg & tally out of hole.
9. GIH w/7" cup type retrievable bridge plug, on-off tool, S.N., & 7" treating pkr & 2-7/8" tbg.
 - A. Set bridge plug @ +6500'.
 - B. Test the bridge plug to +500 psi via the packer.
 - C. Spot 1 sx sand on top of retrievable bridge plug.
 - D. POOH w/2-7/8" tbg, 7" treating pkr, S.N., & on-off tool.
10. GIH w/SOPMA, S.N., & 2-7/8" tbg.
 - A. Land S.N. @ +5816'.
11. GIH w/pump & rods.
 - A. Hang well on & place on test through portable test separator until a stabilized production rate is achieved.
 - B. Report results to the Engineering Department.

RECEIVED

MAR 26 1984

O.C.D.
HOBBS OFFICE