

weight in and out of hole, pit cultures and pump strokes. These should be recorded.

3. Drillman:

Upon hearing the warning blow, go to the valve immediately ahead of the choke manifold and when driller closes the B.O.P.'s, close this valve. Shut off all unnecessary engines and lights and check for fires. Report to the driller and act as a message carrier.

4. Two Roughnecks:

Upon hearing warning blow, report to the driller immediately. One man should contact the tools-pusher or company operator, then report to driller. As soon as driller closes B.O.P.'s, go below and jam locking device. Report back to driller for further instructions.

B. Pit drillits should be held weekly by men working while tripping pipe. Procedure outline in case of a threatened blowout:

1. Driller:

Sound warning whistle and tighten with tongs the inside B.O.P.'s that have been put into string by roughnecks. Prepare the valve plunger and go back in hole with pipe as far as possible. Do not let well gain over 40 bbls. before installing "Below Kelly valve" and picking up kelly. Then proceed as in above operations. After air back pressure is taken out and installed to drill string, drill pipe fluid in pressure is measured by engaging pump only enough to move mud.

2. Derrickmen:

Upon hearing warning whistle, come down from derrick immediately if pipe is not to be run back into hole. Line out pump on hole and proceed as in above operations.

3. Roustabout:

Proceed as in above operations.

4. Two Roughnecks:

Place inside B.O.P.'s into drillstring and make up tight with tongs. If conditions exist, help run pipe in hole or back up kelly and proceed as in above operation for drilling.

E. If the well is shut in with the hydrid, regulate the hydrid closing pressure to the minimum required to keep the hydrid from leaking and run mineral oil on pipe above the hydrid rubber to prevent bearing. Cut off any drill pipe protection sulfurn on joints worked or stripped through the hydrid.