Submit 3 Copies To Appropriate District Office <u>District I</u> 1625 N French Dr. Hobba ND ( 97040)	State of New Mexico Energy, Minerals and Natural Resources		Form C-103 Revised March 25, 1999	
1625 N. French Dr., Hobbs, NM 87240 <u>District II</u> 811 South First, Artesia, NM 87210 <u>District III</u> 1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> 2040 South Pacheco, Santa Fe, NM 87505	OIL CONSERVATION DIVISION 2040 South Pacheco Santa Fe, NM 87505		WELL API NO. 30-025-25616 5. Indicate Type of Lease STATE FEE 6. State Oil & Gas Lease No.	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other SWD Well			<ul> <li>7. Lease Name or Unit Agreement Name:</li> <li>BLINEBRY DRINKARD (DDT SWD</li> </ul>	
2. Name of Operator RICE OPERATING COMPANY 3. Address of Operator 122 W. TAYLOR, HOBBS, NM 88240			<ol> <li>Well No.</li> <li>Y-18</li> <li>9. Pool name or Wildcat</li> <li>SAN ANDRES</li> </ol>	
4. Well Location Unit Letter N feet from theSOUTH line and2259 feet from theWEST line				
Section 18 10. 34	Township 22S Elevation (Show whether Da 19' GL; 3424' KB	Range 37E R, RKB, RT, GR, etc.,	NMPM LEA County	
NOTICE OF INTEN	DESTINCT OF THE DESTINATION TO: UG AND ABANDON		EQUENT REPORT OF:	
	ANGE PLANS	COMMENCE DRIL		
OTHER: 12. Describe proposed or completed op of starting any proposed work). SEE or recompilation.	erations. (Clearly state all per E RULE 1103. For Multiple C	OTHER: tinent details, and giv completions: Attach	/e pertinent dates, including estimated date wellbore diagram of proposed completion	

INSTALL INJECTION PACKER PURSUANT TO NM UIC LETTER 12-01-99: GENERIC PROCEDURE ATTACHED

I hereby certify that the information above is true and complete to the best o	f my knowledge and belief.
SIGNATURE avoly Donan Haynes TITLE OP	ERATIONS ENGINEER DATE 5-3-00
Type or print name CAROLYN DORAN HAYNES	Telephone No. 505-393-9174
(This space for State use)	
APPPROVED BY TITLE Conditions of approval, if any:	DAT

\_



UIC Order Generic Procedure April 3, 2000 Page 3 of 3

## RICE OPERATING COMPANY GENERIC PROCEDURE FOR SWD WELLS INSTALL IPC TUBING AND PACKERS

- 1. Prepare location for pulling unit: anchors, base, etc. Bleed-off well if pressurized.
- 2. Move in and rig up on location with pulling unit. Nipple-down wellhead and nipple-up BOP. Plumb back-flow line to tank if necessary. Set 2 7/8" work string on pipe racks.
- 3. Trip out of hole with injection string laying down on pipe racks. For Duoline tubing, have Rice Duoline representative on location. Record static fluid level.
- 4. Pick up mill tooth bit on work string and trip in hole. Tag for fill. Go in hole with casing scraper if necessary. POOH.
- 5. Rig up wire line (Computalog) and log well, especially in area to set packer.
- 6. Go in hole with Packer and Plug to check casing integrity. Repair casing as necessary.
- 7. Rig up pipe testers and go in hole with injection packer on injection string. Pump packer fluid and set packer within 100' of injection interval.
- 8. Nipple down BOP and nipple up well head. Finish filling casing annulus with packer fluid and prepare for MIT testing.
- 9. Perform MIT. Rig pulling unit down. Clean-up location.

NMOCD, Hobbs Office, will be notified 24 hours in advance of MIT.