

PROPOSED WELL PLANWELL NAME Meyer A-29 No. 10FIELD NMFU

<u>ATTACHMENT</u>	<u>NO.</u>	<u>REQUIRED</u>	<u>NOT REQUIRED</u>
CASING, CENTRALIZERS, SCRATCHERS	<u> </u>	<u> X </u>	<u> </u>
CEMENTING	<u> </u>	<u> X </u>	<u> </u>
MUD PROGRAM	<u> </u>	<u> X </u>	<u> </u>
WELL PLAN OUTLINE	<u> </u>	<u> X </u>	<u> </u>
PORE PRESSURE - FRAC GRADIENT	<u> </u>	<u> </u>	<u> </u>
PROJECTED PROGRESS	<u> </u>	<u> </u>	<u> </u>
CROSS SECTION OR WELL COURSE	<u> </u>	<u> </u>	<u> </u>
HYDRAULICS PROGRAM	<u> </u>	<u> </u>	<u> </u>
BIT PROGRAM	<u> </u>	<u> </u>	<u> </u>
VENDER USAGE LIST	<u> </u>	<u> </u>	<u> </u>

DRILLING AND COMPLETION PROCEDURE

- (1) 0'-1350' Drill 12 $\frac{1}{4}$ " hole. Set and cement surface casing. Pressure test and drill out after 18 hours.
- (2) 1350'-3800' Drill 7 7/8" hole. Pressure test to 300 psi after drilling out shoe. Run open hole logs. Set and cement production casing.
- (3) Detailed completion procedure to be prepared after open hole logs are analyzed. Anticipated 20 to 30 shots, 2,000 gallon acid job, and frac with 20,000 pounds sand (possibly CO₂ frac).