

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDARY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Grace Petroleum Corporation		8. Farm or Lease Name Grizzell Deep
3. Address of Operator 10700 N. Freeway, Suite 620, Houston, Tx. 77037		9. Well No. 1
4. Location of Well UNIT LETTER <u>P</u> <u>330</u> FEET FROM THE <u>South</u> LINE AND <u>543</u> FEET FROM THE <u>East</u> LINE, SECTION <u>5</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Brunson Fusselman
15. Elevation (Show whether DF, RT, GR, etc.) 3423.2' GR; 3438.6'		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Description Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Kill well
- 2) Pull out of hole with tubing
- 3) Set 35' of cement on top of retainer at 7210' (wireline)
- 4) GIH w/tubing
- 5) Set 25 sacks of cement from 7150' to 7050'
- 6) Circulate well with 10 ppg brine + 25 lbs/bbl of salt gel
- 7) Set 25 sacks of cement from 6200' to 6300'
- 8) Set 25 sacks of cement from 3300' to 3400'
- 9) Pull out of hole; perforate 1300' to 1302' (SPF); go in hole
- 10) Set 39 sacks of cement from 1100' to 1300' (in 5-1/2" csg and between 5-1/2" and 8-5/8" csgs)
- 11) Pull out of hole; perforate 350' to 352' (SPF); go in hole
- 12) Set 28 sacks of cement from 350' to 250' (in 5-1/2" csg and between 5-1/2" and 8-5/8" csgs)
- 13) Spot 10 sacks of cement from 0 to 10'
- 14) Cut off 4' below ground level
- 15) Weld on steel plate and I.D. (Operator Name, Lease Name, Section, Township, Range, Distance from Section Lines)

\*Give Oil Conservation Division 24 hours notice before P & A begins.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mike Powell TITLE Engineer DATE 2/26/88

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE MAR 3 - 1988

CONDITIONS OF APPROVAL, IF ANY: