

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-27486
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	NMB 1040

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name 002348 State 2 8016 JV-P
2. Name of Operator BTA Oil Producers	8. Well No. 1
3. Address of Operator 104 S. Pecos, Midland, TX 79701	9. Pool name or Wildcat Wildcat, Strawn
4. Well Location Unit Letter <u>N</u> : <u>660</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>2</u> Township <u>23S</u> Range <u>34E</u> NMPM Lea County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3408' GR 3376' RT

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PROPOSED PROCEDURE:

1. Notify NM OCD 505-393-6161 - MIRU
2. Set 7-5/8" CIBP @ 11830'
3. RIH w/tbg - Spot plugs as shown & tag after spotting  
25 sx plug on top of CIBP  
100' plug 1/2 in & 1/2 out 7-5/8" liner @ 11387'  
100' plug in 9-5/8" @ top Bone Spring @ 8388'  
100' plug in 9-5/8" @ 4900' (13-3/8" csg shoe)
4. Pump a 200 sx plug down 20" - 13-3/8" annulus. Displace to 1400'.  
100' plug in 9-5/8" @ 1565' (20" csg shoe)  
10 sx plug @ surface
5. Cut off wellhead - Install P & A marker.

100' plug @ 3500

CONFIRM PLACEMENT w/ RADIOACTIVE LOG OR TEMPERATURE

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Carolyn Doughton TITLE Regulatory Administrator DATE 11-3-94

TYPE OR PRINT NAME \_\_\_\_\_ TELEPHONE NO. \_\_\_\_\_

(This space for State Use)

NOV 07 1994

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLACING OPERATIONS FOR THE C-103 TO BE APPROVED.