

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-19143

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS MEXICO 88240

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

7. UNIT AGREEMENT NAME

2. NAME OF OPERATOR

AMOCO PRODUCTION COMPANY

8. FARM OR LEASE NAME

Federal "CW" *Com*

3. ADDRESS OF OPERATOR

P. O. Box 68, Hobbs, NM 88240

9. WELL NO.

1

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

10. FIELD AND POOL, OR WILDCAT

Antelope Ridge Atoka

(Unit P, SE/4, SE/4)
660' FEL X 990' FEL

11. SEC., T., R., OR BLK. AND
SURVEY OR AREA

3-23-34

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3377' GL

12. COUNTY OR PARISH

Lea

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose PXA subject well. MI RUSU. Install BOP. POH with production equipment. RIH and set CIBP at 11900' and cap with 35' class H cement. RIH with tbg and displace wellbore with 423 bbl of 10# brine gel. PU to 11470 and spot a 200' class H plug to 11270. (Top Wolfcamp 11370'.) PU to 8540' and spot a 200' class H cement plug to 8340'. (Top of Bone Springs at 8440'.) PU to ~~6340~~ ⁵²⁴⁰ and spot a 200' class H cement to ~~4140~~ ⁵⁴⁴⁰. PU to 4340 and spot a 200' class H cement to 4140'. PU to 3650' and spot a 200' class H cement plug to 3450'. (Note cement top of 7-3/4" casing at 3532'.) Perforate at 1815 with 4 JSPF. Use 4' casing gun at 90° phasing. RIH and set cement retainer at 1615'. Pump 360 sx class H. Spot surface plug. Cut off wellhead and install dry hole marker.



18. I hereby certify that the foregoing is true and correct

SIGNED *Charles S. Brownlee*

TITLE Administrative Analyst

DATE 1-23-87

(This space for Federal or State office use)

APPROVED BY *Orig: Sgd. Charles S. Brownlee*

TITLE

DATE 1-29-87

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED
FEB 2 1967
OCD
MAILING OFFICE