

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLI  
(Other instructions on re-  
verse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. NM-13126
2. NAME OF OPERATOR Stevens & Tull, Inc.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. Box 11005, Midland, Texas 79702	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1650' FSL & 2310' FEL, Sec. 31, T-22-S, R-36-E	8. FARM OR LEASE NAME Meyer Federal
14. PERMIT NO. Unknown	9. WELL NO. 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3512.8' GL	10. FIELD AND POOL, OR WILDCAT Jalmat Yates SR
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 31, T-22-S, R-36-E
	12. COUNTY OR PARISH Lea
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

- 1) Perf 1 jet shot per location 3858,64, 75 & 79 (4holes).
- 2) Acidize with 2500 gallons 15% NE-FE.
- 3) Swab test water.
- 4) Set CIPB at 3850' with 2 sacks cement on top.
- 5) Perf 1 jet shot per location at 3796, 3800, 04. (3 holes).
- 6) Acidize with 1500 gallons 15% NE-FE.
- 7) Swab dry.
- 8) Set CIPB at 3790' - No cement - intend to KO.
- 9) Perf 1 jet shot per location at 3582,85, 92, 3602, 19, 22, 25, 28, 31, 34, 37, 40, 43, 46, 74, 77, 80, 83, 85, 3701, 09, 11, 32, 38, & 56 (26 holes).
- 10) Acidize with 2500 gallons 15% NE-FE.
- 11) Swab dry.
- 12) Prep to frac.

ACCEPTED FOR RECORD

FEB 16 1990

CARLSBAD, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Rodney L. Seale *Rodney L. Seale* Engineer

DATE 2/8/90

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side