

EXHIBIT A
OPERATIONS PLAN
TOCO, L.L.C.
MARY FEDERAL #2
SECTION 25, T 23S, R33E
LEA COUNTY, NEW MEXICO

1. Drill a 17 ½" hole to approximately 40'.
2. Run 13 3/8" 94.0 ppf casing and cement. Run centralizers on every other joint above the shoe. Apply thread lock to bottom two joints and guide shoe.
3. Wait on cement twelve hours prior to cutting off.
4. Nipple up an annular BOP system and test casing. WOC twenty-four hours prior to drilling out.
5. Drill an 11" hole to approximately 5100'.
6. Run 8 5/8" 34 & 28 ppf casing and cement. Run guide shoe on bottom and float collar two joints from bottom. Centralize every other joint for bottom 400' of casing and place two centralizers in surface casing. Thread lock bottom 2 joints.
7. Wait on cement for twelve hours prior to cutting off.
8. Nipple up and install a Double Ram and Annular BOP system with choke manifold.
9. Test BOP system and casing.
10. Drill a 7 7/8" hole to ± 12160'. Run log.
11. Run 5 ½" 15 ½ ppf casing set @ 12,160' and cement. Tie back into intermediate.
12. Nipple down BOP. Set slips. Cut off casing. Nipple up BOP Stack and test.
13. Test casing.
14. Run production equipment and test well as necessary.