

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-229
7. Lease Name or Unit Agreement Name J. F. Janda (NCT-G)
8. Well No. 1
9. Pool name or Wildcat Jalmat Tansil Yates 7-Rvrs
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3355' GR

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator  
Meridian Oil Inc.

3. Address of Operator  
P.O. Box 51810, Midland, TX 79710-1810

4. Well Location  
Unit Letter A : 990 Feet From The North Line and 990 Feet From The East Line  
Section 24 Township 23S Range 36E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Notify OCD prior to commencing plugging operations.

RIH w/casing scraper to +/- 2800', set cmt retainer @ +/-2765'. Squeeze open hole under retainer with 100 sx Cl. C cmt. Spot cmt plug @ 2615'-2765' (20 sx). Circ hole with 9 ppg gelled brine.

Set cement plug @ 1260' - 1380' (15 sx). RIH W/Packer to determine if casing holes are above or below 350'. Use a retainer in next step if holes are above 350'.

Perforate 4 squeeze holes @ 350'. Squeeze 5-1/2" x 9-5/8" annulus by pumping 150 sx cmt (40% excess) down 5-1/2" csing to surface (do not displace). Use Cl. C cmt.

Cut off casing 3' below ground level and install P&A marker. Clear and restore location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Connie L. Malik TITLE Reg. Compliance Rep. DATE 3/31/92

TYPE OR PRINT NAME Connie L. Malik TELEPHONE NO. 915-688-6898

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: