

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.


LC 030167 A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.



2. NAME OF OPERATOR

Continental Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 460, Hobbs, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface 330' FNL & 990' FEL of Section 24, T-26S,
R-36E, Lea County, New Mexico, NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

2936 DF

8. FARM OR LEASE NAME

McCallister A-24

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Jalmat Pool-Yates

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 24, T-26S, R-36E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Perforate Additional Pay ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

To increase productivity in the subject well it is proposed to perforate additional pay using the following procedure:

1. Pull rods
2. Set RBP @ 3070' (7" 24# casing) W/ wireline.
3. Perforate Yates W/1 JSPF @ 3045', 3050', 3059', 3063', (hole size 3/8" or smaller).
4. Acidize perforations down 2 1/2" tubing W/3000 gal LSTNE acid using ball sealers.
5. Swab back acid water and test for 48 hours.
6. Run pressure bomb in hole and leave shut in for 72 hours for pressure buildup.
7. If upper Yates perforations have low productivity, pull RBP and run rods and casing pump.

Your approval of the above work is requested.

18. I hereby certify that the foregoing is true and correct

SIGNED

Signed: Robert Gordon

TITLE Staff Supervisor

DATE 6-10-65

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

USGS-5, NMOCC-2, LPT PAN AM HOBBS-3, ATL ROS-2, CALIF AND APPROVED

*See Instructions on Reverse Side

JUN 14 1965

J. L. GORDON
ACTING DISTRICT ENGINEER