Submit 3 Copies to Approriate District	State of Ne				
Office	Enorgy, Minerals an	id Natural Resouces	FORM C-103		
DISTRICT I			Revised March 25, 1999		
625 N. French Dr., Hobbs, NM 88240	OH COMERDIA	TION DIVISION	WELL API NO.		
DISTRICT II	OIL CONSERVATION DIVISION 2040 South Pacheco		30-025-10610		
311 South First, Artesia, NM 88210			5. Indicate Type of Lease		
DISTRICT III	Santa Fe, I	NM 87505	STATE FEE		
1000 Rio Brazos Rd., Aztec, NM 87410					
<u>DISTRICT IV</u>			6. State Oil & Gas Lease No.		
2040 South Pacheco, Santa Fe, NM 87505					
SUNDRY NO	OTICES AND REPORTS ON	I WELLS			
(DO NOT USE THIS FORM FOR PRO	POSALS TO DRILL OR TO DEEPE	7. Lease Name or Unit Agreement Name			
DIFFERENT RESERVOIR. USE "APP	LICATION FOR PERMIT" (FORM	C-101) FOR SUCH			
DPOSALS.)			Skelly Penrose 'A' Unit		
Type of Well:					
✓ OIL WELL	GAS WELL OTHER				
2. Name of Operator			8. Well No.		
Apache Corporation			62		
3. Address of Operator		9. Pool name or Wildcat			
2000 Post Oak Blvd. Ste. 100.	Houston, Texas 77056-4400	Langlie-Mattix; 7 Rvrs-Q-Grayburg (37240)			
4. Well Location Unit Letter K:	2200 Feet From The SOU	1th Line and 2200	Feet From The West Line		
	225	37E NMI	PM Lea County		
Section 3 Tow	wnship 23S Range 10. Elevation (Show whether I		THE EDGE SOURCE		
	3297' GR				
		ate Box to Indicate Nature of Notic	e, Report, or Other Data		
NOTICE OF INT			BSEQUENT REPORT OF:		
_		[] D dial 18/a.	ule Dubarian Casina		
Perform Remedial Work Plug and Abandon		Remedial Wo	rk Altering Casing		
Temporarily Abandon Change Plans		Commence D	Commence Drilling Operations		
Pull or Alter Casing		Casing Test and Cement Job			
Other		☐ Other			

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

MIRU. Nipple down wellhead. Nipple up BOP. Run in hole w/ coiled tubing to 3450'. Spot 50 sx Class "C". 8/24/00 cement plug w/ 2% CaCl @ 3450' - 3298'. Pull out of hole & wait on cement 4 hours. Run in hole w/ coiled tubing & tagged top of cement @ 3322'. Pull up hole to 3200'. Circulate 60 bbls mud laden fluid. Pull up hole to 1230'. Spot 100 sx Class "C" cement plug @ 1230' - 926'. Pull out of hole. Wait on cement.

Run in hole w/ coiled tubing & tagged top of cement @ 937'. Pull up hole to 250'. Spot 100 sx Class "C" 8/25/00 cement plug @ 250' to surface. Pull out of hole. Top off w/ cement. Install P&A marker.

	1				
I hereby certify that the batternation SIGNATURE	above is true and complete to the best of my knowledge and bel	tief. TITLE	Sr. Engineering Technician	DATE _	9/25/00
	Debra J Anderson		TELEPH	IONE NO.	713-296-6338
(This space for State Use) APPROVED BY	THE TITLE	ft	DATE	3-	5-01
CONDITIONS OF APPROVAL, IF	FANY:	7			
CWW					

Other