

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
N.M. Oil Cons. Division No. 1004-0135
P.O. Box 1980 Expires: March 31, 1993
Lease Designation and Serial No.
Hobbs, NM 88241C 032452A

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

APACHE CORPORATION

3. Address and Telephone No.

3300 N. A STE. 8220 MIDLAND, TX 79705

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650' from South line & 660' from East line, Sec. 9, T-23S,
R-37E

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8910088420

8. Well Name and No.

SKELLY PENROSE A UNIT #56

9. API Well No.

3002510681

10. Field and Pool, or Exploratory Area

LANGLIE MATTIX 7RIVRS Q GRI

11. County or Parish, State

Lea

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

WELL TO PLUGGED AND ABANDONED AS FOLLOWS:

Junk in hole @ 3414'

- 1) RIH set CIBP @ 3400' w/15 sxs cmt.
2) Spot cement plug from 1090-1190' w/15 sxs. cmt.
3) Spot cement plug from 50' to surface w/10 sxs.
4) Install 4-1/2" dry hole marker.

4) Spot cement plug from 324-424' w/15 sxs.

2) Perforate 5 1/2" casing @ 1190' &
squeeze with sufficient cement
in the annular space between 8 1/2"
casing & 5 1/2" casing

RECEIVED

SEP 28 11 49 AM '96

14. I hereby certify that the foregoing is true and correct

Signed Sylvia Shoemaker SYLVIA SHOEMAKER Clerk III

Date 8-21-96

(This space for Federal or State office use)

(ORIG. SCD) DAVID R. GLASS

Approved by _____
Conditions of approval, if any:

Title _____

SEP 18 1996

Diagram illustrating the wellbore completion stages and casing sets for TD 3665'.

Key completion stages and casing sets shown:

- CMT PLUG 50' TO SURFACE W/10 SX CMT
- TOC @ SURFACE
- 8-5/8" 24# CSG SET @ 364' CMT'D W/175 SX CMT
- CMT PLUG 1090-1190' W/15 SX CMT
- TOP OF CMT @ 1572'
- CIBP SET @ 3400' W/15 SX CMT
- PERFS @ 3520-3632'
- 5-1/2" 14# @ 3658' CMT'D W/275 SX
- PBTD 3645'
- TD 3665'