

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
☒ FEDERAL ☐
 5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection	7. Unit Agreement Name
2. Name of Operator Samedan Oil Corporation	8. Farm or Lease Name Hughes Federal
3. Address of Operator 10 Desta Drive, Suite 240 East, Midland, Texas, 79705	9. Well No. 1
4. Location of Well UNIT LETTER P , 660 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 17 TOWNSHIP 23 RANGE 37-E NMPD.	10. Field and Pool, or Wildcat Langlie Mattix-SK-WU GB
15. Elevation (Show whether DF, RT, GR, etc.) 3335' KB	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIATION WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Unseat packer at 3446' & trip out of hole.
2. Set CIBP @ 3450'+.
3. Dump 35' (3 sx) cement on top of CIBP.
4. Perf 4 squeeze holes at 3400'.
5. Establish circulation between 4½ and 7" casing.
6. Mix and pump 200 sx cement to circulate to surface.
7. Pump 10 sx plug at 2900'.
8. Pump 10 sx plug at 2600'.
9. Dump 5 sx at surface.
10. Install pipe marker.
11. Clean location.

Work will be completed prior to February 28, 1987.

FOR RECORD ONLY

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Nick Hood Nick Hood TITLE Engineer DATE 1/12/87

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: