

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.  
LC 030556B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.  
Stevens B #15

9. API Well No.  
30-25-10792

10. Field and Pool, or Exploratory Area  
Jalmat Gas

11. County or Parish, State  
Lea, NM

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well  
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator  
Conoco, Inc.

3. Address and Telephone No.  
10 Dista Dr. Ste 100W, Midland, TX 79705

4. Location of Well (Range, Sec., T., R., or Survey Description)

1650' F81 & 1650' F82  
Sec. 18 T-23S, R-37E  
FWL & FWL

Unit F

**12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

**TYPE OF SUBMISSION**

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

**TYPE OF ACTION**


- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to plug and abandon this well according to the following procedure and the attached wellbore diagrams:

1. Set CIBP at 2650' and spot 25 sxs cement on top.
2. Load hole with gelled brine mud.
3. Perforate 5 1/2" casing at 1275'.
4. Set cement retainer at 1150' and squeeze with 100 sxs cement.
5. Perforate 5-1/2" casing at 350' and circulate 70 sxs cement.
6. Install dry hole marker and clean location.



14. I hereby certify that the foregoing is true and correct

Signed

Title

Sr. Conservation Coordinator

Date

4/11/96

(This space for Federal or State office use)

Approved by

(ORIG. SEC.) JOE G. LARA

Title

PETROLEUM ENGINEER

Date

5/7/96

Conditions of approval, if any:

See attached.