

Drinkard Sandy Member (Tubb)	5980'
Base of Permian and top of the Devonian	7200'
	8300'
Silurian	8300'
Montoya	8600'
Simpson	8900'
McKee Sand Member	9275' (Base 9450')

The most probable drilling-in procedure will be to test the top ten or fifteen feet of McKee Sand, run an electric log, and then set 7" OD casing. The well will then be cored to total depth with oil base mud and a radio active log run from the base of the intermediate string to total depth.

In the event that it is later decided to set casing on bottom and perforate in the McKee Sand instead of following the above procedure, the well will first be drilled to total depth with water base mud, the McKee Sand will be tested, an electric log will be run from the base of the intermediate string to total depth and the production casing run to total depth. No other special drilling-in procedure is anticipated.