

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLIC
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. NM-27723	
2. NAME OF OPERATOR Texaco Inc.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P.O. Box 728, Hobbs, New Mexico 88240		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface Unit Letter L, 1980 FSL & 660' FWL		8. FARM OR LEASE NAME E.E. Blinbry "B" Federal NCT-2	
14. PERMIT NO. 30-025-10844		9. WELL NO. 2	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3765' DF		10. FIELD AND POOL, OR WILDCAT Langlie Mattix Seven Rivers Queen	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA S26, T23S, R37E	
		12. COUNTY OR PARISH Lea	
		13. STATE NM	

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANE

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU.
2. TIH with workstring and circulated 10# gallon brine.
3. Tag CIBP at 3465' and spot 35' cement plug on 5 1/2" CIBP.
4. Pulled up and spot 100' cement plug 2394' to 2494'.
5. Pulled up and spot 100' cement plug 1056' to 1156'.
6. Perforate 5 1/2" casing at 800' with 2 shots. Circulated down 5 1/2" casing up 8 5/8" casing to top with brine water.
7. Cement with 424 sacks Class "C" cement. Circulate 10 sacks to pit.
8. Cut off wellhead. Install marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Dist. Adm. Supvr.

DATE

06/04/86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side