P. O. BOX 1000

HOBBS, NEW MEXICO 882401-WIO's

Form 9–331

le respectation ne legal subspectation

FOR

DISTRICT SUPERVISOR

JAMES A. GILLHAM . See Instructions on Reverse Side

Form Approved.

| Dec. 1973 | Budget Bureau No. 42-R1424 |
|---|---|
| UNITED STATES | 5. LEASE |
| DEPARTMENT OF THE INTERIOR | LC-060825-a |
| GEOLOGICAL SURVEY | 6. IF INDIAN, ALLOTTEE OR TRIBE NAME |
| SUNDRY NOTICES AND REPORTS ON WELLS | 7. UNIT AGREEMENT NAME |
| (Do not use this form for proposals to drill or to deepen or plug back to a different | Myers Langlie Mattix Unit |
| reservoir. Use Form 9–331–C for such proposals.) | 8. FARM OR LEASE NAME |
| 1. oil gas well other Water Injection Well | 9. WELL NO. |
| 2. NAME OF OPERATOR Getty Oil Company | 5 10. FIELD OR WILDCAT NAME |
| 3. ADDRESS OF OPERATOR | Langlie Mattix |
| P.O. Box 730 Hobbs, NM 88240 | 11. SEC., T., R., M., OR BLK. AND SURVEY OF |
| 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 | |
| the January | Sec. 30-T23S-R37E |
| AT SURFACE: Unit ltr. A, 660' FNL & 660' FEL | 12. COUNTY OR PARISH 13. STATE |
| AT TOP PROD. INTERVAL: | Iea NM |
| AT TOTAL DEPTH: | 14. API NO. |
| 16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE | |
| REPORT, OR OTHER DATA | 15. ELEVATIONS (SHOW DF, KDB, AND WD |
| REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF: | 3330' DF |
| TEST WATER SHUT-OFF | |
| FRACTURE TREAT | 그 그 그 그 그 생생들은 그 그 사람들이 다 |
| SHOOT OR ACIDIZE | |
| REPAIR WELL XX | (NOTE: Report results of multiple completion or zon |
| PULL OR ALTER CASING | change on Form 9–330.) |
| CHANGE ZONES | |
| ABANDON* | |
| (other) | |
| 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly st | ate all pertinent details, and give pertinent date |
| including estimated date of starting any proposed work. If well is measured and true vertical depths for all markers and zones pertin | directionally drilled give subsurface locations and |
| 1. Rig up pulling unit. | |
| 2. Install BOP. | JOIL & GAS TV P |
| 3. TOH with injection tubing and packer. | ROSWELL NEW MEXICO |
| 4. Set RBP @ 3185' in 4 1/2" liner | |
| 5. Set 7" pkr. above liner & pressure test | to 2000 psi. |
| 6. Dump 10' sand on top of RBP. | |
| 7. Squeeze cement liner top w/100 sxs clas | s "C" cement |
| 8. WOC 24 hours. | |
| 9. Drill out cement. | |
| 10. Perforate the Langlie Mattix 3498-3651' | |
| 11. Acidize w/2600 gallons 15% HCL. | |
| 12. Return to injection | |
| Subsurface Safety Valve: Manu. and Type | Set @ F |
| 18. I hereby cartify that the foregoing is true and correct | |
| SIGNED SIGNED SUPERINT | sendent _{DATE} September 27, 1982 |
| APPROVE Only space for Federal or State | office use) |
| 10.4 | |
| CONDITIONS OF APPROVAL, IF ANY: | DATE |
| OCT 6 1982 | |