

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-72

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

0+6 - NMOCD-P.O. Box 1980 1-Laura Richrdson
Hobbs, NM 88240 Midland
1 - Midland Admin. Unit - Mr. J.A.
1 - Foreman - HC 1 - Engr. RH 1 - File

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Getty Oil Company (Western Gas Company)	8. Farm or Lease Name Cowden
3. Address of Operator P.O. Box 703 Hobbs, NM 88240	9. Well No. 1
4. Location of Well UNIT LETTER A 330 FEET FROM THE North LINE AND 330 FEET FROM East THE LINE, SECTION 31 TOWNSHIP 23 RANGE 37 NMPM.	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3321' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Clean out well to 3435'.
- Circulate hole with 10# salt gel.
- Spot 100' cement plug from 3435'-3335'.
- Pull bit to 2700' and allow plug to set-up.
- Tag to insure proper placement of cement.
- Spot 100' of cement across top of 7" casing at 2539'.
- Pull but to 2000' and allow plug to set-up.
- Tag plug from 2489'-2589' to insure proper placement.
- Spot 100' of cement from 1269'-1169' in bottom of 9 5/8" casing.
- Pull up allow cement to set-up and tag to insure proper placement.
- Spot 137' plug from inside 9 5/8" csg. (312') to inside of 13" csg. (175').
- Allow cement to set-up and tag to insure proper placement.
- Set 10 sk. surface plug.
- Install permanent marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dale R. Crockett TITLE Area Superintendent DATE December 22, 1983

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT SUPERVISOR

CONDITIONS OF APPROVAL, IF ANY:

DATE DEC 30 1983