

<u>Stage</u>	<u>Fluid</u>	<u>ppg</u>	<u>Volume (gal)</u>
Pad	65-Q Foam	0	11000
1	65-Q Foam	1	2000
2	65-Q Foam	2	3000
3	65-Q Foam	4	5000
4	65-Q Foam	6	6000
5	65-Q Foam	8	2000
Flush	65-Q Foam	0	580

Shut well in for 90 minutes then open on 8/64" choke and flow back. When well dies release packer and POOH. RIH with notched collar and clean out to PBTD. POOH and lay down workstring. Run production tubing (2 3/8" and 2 7/8") to ±2600'. Swab well in. Production personnel will lower tubing after 2 weeks.

7. ND BOP, NU wellhead. Swab well in. Report rates and pressures to Midland Office.

Approved: _____ Date: _____
T. J. Harrington