

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPlicate  
(Other instructions on  
verse side)

Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

LC 063916

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Moberly

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Rhodes Yates-Seven Rivers

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 17, T26S, R37E

12. COUNTY OR PARISH 13. STATE

Lea

N.M.

1. OIL WELL ☐ GAS WELL ☒ OTHER P&A

2. NAME OF OPERATOR

El Paso Natural Gas Company

3. ADDRESS OF OPERATOR

1800 Wilco Building, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

660' FSL, 1980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

2,951'

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Rig up pulling unit. Remove wellhead, pull and lay down 2 3/8" tubing. Go in hole with 2 7/8" work string to top of fill at 3,060'. Spot 75 sacks of Class "H" cement to approximately 2,750'. Allow proper time for cement to set up and tag top of plug. Pump 50 bbl mud from 2,750' to 1,300'. Final free point of 7" casing and cut casing above free point. Recover approximately 1,200' of casing. Run in 2 7/8" to 1,300', spot 250 sacks Class "H" cement to 550' and pull tubing out of hole. Allow cement to set up, tag top of plug, pump 45 bbl mud down tubing from 550' to 100'. Spot surface plug of 50 sacks Class "H" cement, erect dry hole marker with pertinent information. Cover all pits, rat hole and cellar. Clean location of all equipment, bases, pipe, junk and trash. Rip location and access roads and restore surface to natural conditions or to landowners specifications.

SEE ATTACHED FOR  
CONDITIONS OF APPROVAL

18. I hereby certify that the foregoing is true and correct

SIGNED

C. C. Goodwin

TITLE Administrator Prod. Services

DATE 10-13-76

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED  
AS AMENDED  
OCT 18 1976

ARTHUR R. BROWN  
DISTRICT ENGINEER

\*See Instructions on Reverse Side