

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. Unknown <u>30-025-12049</u>
5. Indicate Type of Lease <u>Federal</u> STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. NMJ - 538
7. Lease Name or Unit Agreement Name South Leonard Unit Tr. 4
8. Well No. 15
9. Pool name or Wildcat South Leonard Queen
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 2992 DF

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Injection
2. Name of Operator Wood, McShane & Thams
3. Address of Operator P. O. Box 968, Monahans, TX 79756
4. Well Location Unit Letter <u>M</u> : <u>660</u> Feet From The <u>West</u> Line and <u>990</u> Feet From The <u>South</u> Line Section <u>24</u> Township <u>26 S</u> Range <u>37 E</u> NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 2992 DF

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Plugging Procedure: Work to begin A.S.A.P.

Shoe Plug: Set C.I.B.P. immediately above 5½" casing shoe & spot 35' of cement on top of C.I.B.P. or spot 100' cement plug immediately above 5½" casing shoe (Plug must be tagged). Load hole with 10# brine with 25# gel/bbl.

Plug Across Salt Section: (At approx. 1110') Spot 100' plug inside 5½" casing. Plug to be Class C cement with 2% CaCl<sub>2</sub>. W.O.C. & tag plug. Load hole w/10# brine w/25# gel/bbl.

Surface Plug: Spot 10 sx Class C Cement w/2% CaCl<sub>2</sub>.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE R. Cory Richards TITLE Petroleum Geologist DATE 7/16/90

TYPE OR PRINT NAME R. Cory Richards TELEPHONE NO. (915) 943-753

(This space for State Use)

**FOR RECORD ONLY**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: