

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-1431

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection</u>	7. Unit Agreement Name <u>Rhodes Yates Unit</u>
2. Name of Operator <u>Texaco Inc.</u>	8. Farm or Lease Name <u>Rhodes Yates Unit</u>
3. Address of Operator <u>P. O. Box 723, Hobbs, New Mexico 88240</u>	9. Well No. <u>7</u>
4. Location of Well UNIT LETTER <u>F</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>231</u> FEET FROM THE <u>West</u> LINE, SECTION <u>27</u> TOWNSHIP <u>26-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat <u>Rhodes Yates</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>2990' (DF)</u>	12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Release pkr. & pull tubing.
2. Set RBP @ 2950', & spot 3 sx. sand on plug.
3. Locate leak w/pkr. test. Set pkr. above leak. Establish circulation.
4. Squeeze leak w/required cement. If cement does not circulate, run temperature survey. WOC. DOC. Test.
5. Pull RBP & clean out to TD.
6. Run injection equipment & return to injection.

24 HOURS PRIOR TO STARTING WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 3/12/81

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: