

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1431	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER <input type="checkbox"/>	7. Unit Agreement Name Rhodes Yates Unit
Name of Operator TEXACO Inc.			8. Firm or Lease Name
Address of Operator P.O. Box 728, Hobbs, N.M. 88240			9. Well No. 6
Location of Well UNIT LETTER <u>C</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>27</u> TOWNSHIP <u>T-26S</u> RANGE <u>R-37E</u> N.M.P.M.			10. Field and Pool, or Wildcat Rhodes Yates
15. Elevation (Show whether DF, RT, GR, etc.) 2996' (GR)			12. County Lea

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods and pump. Install BOP.
2. Clean out.
3. Spot w/3 drums of scale converter mixed 50:50 w/fresh water across open hole. Pull up and set pkr.
4. Pump 3 additional drums of scale converter mixed 50:50 w/fresh wtr. to the open hole.
5. Acidize open hole w/3000 gal NE HCL acid w/clay stabilizer in 3 stages using 1000# R.S. between stages.
6. Reset pkr and squeeze open hole w/2 drums of scale inhibitor mixed.
7. Pull workstring and pkr.
8. Rerun production equipment and return to production.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. B. Loh TITLE Dist. Opr. Mgr. DATE 3/27/85

APR - 1 1985

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAR 29 1985

202
MAY 1985