

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions
reverse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM-088451

25741

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. NAME OF OPERATOR TEXACO Inc.	
3. ADDRESS OF OPERATOR P. O. Box 728 - Hobbs, New Mexico 88240	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2310' FSL, 2310" FWL, Section 27, Township 27-S, Range 37-E, Unit Letter K, Lea County, New Mexico.	
14. PERMIT NO. Regular	15. ELEVATIONS (Show whether DF, RT, GR, etc.) Unknown

7. UNIT AGREEMENT NAME Rhodes Yates Unit	
8. FARM OR LEASE NAME Rhodes Yates Unit	
9. WELL NO. 11	
10. FIELD AND POOL, OR WILDCAT Rhodes Yates	
11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA Sec. 27, T-27S, R-37E	
12. COUNTY OR PARISH Lea	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☐
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☒ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Pull rods & tubing. Install BOP.
2. Set RBP @ 2816' & dump 3 sks. sand on plug.
3. Set packer in 7" csg @ 424'.
4. Squeeze 7" csg leak at 530' w/150 sx Class 'C' cement using 4% Halad 22 w/.3% CFR-2 and 10# salt per sack. Follow with 50 sacks Class 'C' cement w/2% CaCl. Circulate.
5. Drill out cement. Test casing.
6. Run rods & tubing. Test and return to production.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Asst. District Supt.

DATE 10-27-75

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

