

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. OIL CONS. COMMISSION  
P.O. BOX 1980  
HOBBS, NEW MEXICO 88240

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Sea Sand Oil Co.

3. Address and Telephone No.

P.O. Box 101777 Ft. Worth, TX 76185 (817) 336-3881

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' N. of S. Line, 660' E. of W. Line Sec 33  
Township 26 South - Range 37 East

050107 B

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA, Agreement Designation

N/A

8. Well Name and No.

Mary E. Wills Federal #3

9. API Well No.

300251210000S1

10. Field and Pool, or Exploratory Area

Scarborough Yates-7 Rivers

11. County or Parish, State

Lea County, N. M.

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Rig up. Install B.O.P. equipment.
2. Tag C.I.B.P. at 3150. Circulate hole with 9# mud (Perforations 3178 to 3287). Cap C.I.B.P. with 50' cement plug. Tag plug.
3. Perforate 2700'. Squeeze, Set 100' cement plug 2700' to 2600' (B.O.S. at 2650' T.O.S. at 1200'). Tag plug.
4. Perforate at 1250'. Squeeze. Set 100' plug 1250' to 1150'. Tag plug.
5. Perforate at 650'. Squeeze. Set 100' cement plug 650' to 550'. 8 5/8 shoe at 612'. Tag plug.
6. Locate hole in 4 1/2" casing. Bull head cement down 4 1/2" casing. Back up between annulus 8 5/8 & 4 1/2 to surface.
7. Cut off well head. Install marker.

RECEIVED  
JUN 15 10 55 AM '94  
OIL & GAS  
AREA

14. I hereby certify that the foregoing is true and correct

Signed Joe G. Lara

Title Agent

Date 6/14/94

(This space for Federal or State office use)

(ORIG. SGD.) JOE G. LARA

Title PETROLEUM ENGINEER

Date 6/22/94

Approved by \_\_\_\_\_  
Conditions of approval, if any:

See attached.

RECEIVED

1964

RECEIVED  
OFFICE