

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-9312

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
Skelly Oil Company	West Dollarhide Queen Sand Unit
3. Address of Operator	9. Well No.
P. O. Box 1351, Midland, Texas 79701	53
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER A , 810 FEET FROM THE North LINE AND 810 FEET FROM THE East LINE, SECTION 5 TOWNSHIP 25S RANGE 38E NMPM.	Dollarhide Queen
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3160' DF	Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is in the lower one-third of the unit area in which water break through problems have been experienced. The cost of operating wells in this area has become excessive, and we propose plugging this well as follows:

- 1) Rig up pulling unit. Pull rods and tubing.
- 2) Set 5-1/2" bridge plug at 3640'.
- 3) Circulate hole with 10# mud.
- 4) Spot 10 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement across top of salt section at 1230'.
- 6) Spot 10-sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED (Signed) J. R. Avent J. R. Avent TITLE Dist. Admin. Coordinator DATE Nov. 20, 1972

APPROVED BY Orig. Signed by Joe D. Ramey TITLE Dist. I, Supr. DATE NOV 22 1972