

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

OCT 16 1967

O. G. C.
ARTESIAL OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
B-9312

7. Unit Agreement Name

8. Farm or Lease Name

9. Well No.

10. Field and Pool, or Wildcat

Dollarhide Brinkard

12. County

Lee

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER-

2. Name of Operator
SEKELY OIL COMPANY

3. Address of Operator
P. O. Box 730 - Hobbs, New Mexico 88240

4. Location of Well
UNIT LETTER **G** **1656** FEET FROM THE **North** LINE AND **1980** FEET FROM
THE **East** LINE, SECTION **5** TOWNSHIP **258** RANGE **28E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

3159' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐

CHANGE PLANS ☐

OTHER **Repair Casing Leak** ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up Workover Rig.
2. Pull rods and tubing.
3. Perforate 1' interval with 4 shots/ft. at 3873'. (Base of Queen interval @ 3773'.)
4. Run retrievable bridge plug and RTTS Tool. Set B.P. at 3900'. Dump sand or gel on top of retrievable B.P. Set RTTS above perforated interval.
5. Circulate behind casing through bradenhead and cement back to surface. (650 Sacks.)
6. If unable to circulate to surface or up into 8-5/8" CD casing, squeeze perforations with 50 sacks. Perforate at 3590' and squeeze with 100 sacks.
7. Drill out cement and pull retrievable bridge plug.
8. Clean out to T.D. with sand pump.
9. Run rods and tubing.
10. Return well to producing status.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

(Signed) **V. E. Fletcher**

SIGNED _____

TITLE **District Superintendent**

DATE **October 12, 1967**

V. E. Fletcher

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY: