

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Maralo, Inc.

3. Address and Telephone No.

P. O. Box 832, Midland, Texas 79702 0832 915 684-7441

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1651.98' FNL & 330' FWL of Sec 6, T-26-S, R-38-E

Unit E

5. Lease Designation and Serial No.

E-04-06-T-26-S-R38-E

6. If Indian, Allottee or Tribe Name

NM-0889

7. If Unit or CA, Agreement Designation

8. Well Name and No.

M. D. Self #4

9. API Well No.

10. Field and Pool, or Exploratory Area

Langlie Mattix 7 Rivers On

11. County or Parish, State

Lea

12 CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Notify NMOCC when plugging procedure begins.
2. Set CIBP @ +/-3220'. Cap w/35' cnt. (5 sx)
3. Load hole with 10#/gal mud laden fluid.
4. Cut and pull 5 1/2" csg. Est. top of cnt @ 985'.
5. Set 100' (30 sx) cnt plug across 5 1/2" csg. stub, 50' inside and 50' outside.
6. Set 100' (45 sx) cnt plug across base of 8 5/8" csg 385 - 485'; 50' inside and out
7. Set 10 sx cnt plug @ surface.
8. Remove wellhead, cut off csg and weld plate on.
9. Clean up location and place dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed

Title Agent

Date 3-5-92

(This space for Federal or State office use)

Approved by

Title

Date 3-17-92

Conditions of approval, if any: