

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

**HOBBS OFFICE O. G. C.**  
NEW MEXICO OIL CONSERVATION COMMISSION

**MAR 8 11 51 AM '66**

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.  
**B-1484**

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>DRY HOLE</b>	7. Unit Agreement Name
2. Name of Operator <b>Ernest A. Hanson</b>	8. Farm or Lease Name <b>State "0"</b>
3. Address of Operator <b>P. O. Box 1515, Roswell, New Mexico</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>D</b> , <b>560</b> FEET FROM THE <b>North</b> LINE AND <b>330</b> FEET FROM THE <b>West</b> LINE, SECTION <b>32</b> TOWNSHIP <b>26-S</b> RANGE <b>37-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Jalmat</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>2931' GL</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**It is proposed to plug and abandon the captioned well in the following manner with all plugs to be set in heavy mud, to wit:**

1. Pull 5-1/2" casing from approximately 2650' (temperature survey).
2. Set 25 sx. cement plug @ total depth 3187' (cover perms 3150-81').
3. Set 25 sx. cement plug @ approx. 2650' to cover 5-1/2" csg. stub.
4. Set 25 sx. cement plug @ 1312' in Top of Salt.
5. Set 25 sx. cement plug @ 311' in bottom of 8-5/8" surface casing.
6. Set 10 sx. cement plug @ surface & erect regulation dry hole marker.
7. Clean-up location for final NMOCC inspection & approval.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Harry F. Schram* TITLE **Geologist** DATE **Feb. 24, 1966**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: