

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPL
(Other instruction
verse side)

TE
re

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM 0448921-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Mexico-Federal "P"

8. FARM OR LEASE NAME

Mexico-Federal "P"

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Rustler

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 21, T-26-S, R-35-E

12. COUNTY OR PARISH 13. STATE

Lea

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☒ OTHER SWD

2. NAME OF OPERATOR

Texaco Producing Inc.

3. ADDRESS OF OPERATOR

P. O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

1630' FWL & 2330' FNL, Section 21, T-26-S, R-35-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANE

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

1) Move-in, Rig-up Pulling Unit.

2) Push cement retainer at 350' to bottom.

3) Set a 4-1/2" CIBP on wireline at 1475'. Dump 8 sacks Class "H"
cement or 100' plug on top.

4) Trip in hole with tubing. Circulate hole full with 10# gelled brine.
Spot 82 sacks Class "H" cement from 1050' to 100'. POH. SION.

5) Squeeze holes at 40', down 4-1/2" casing, with 25 sacks Class "H"
cement.

6) Tag cement top. Fill to surface with Redimix, as needed.

7) Install marker and clean location.

Verbal approval obtained from Mr. Bob Pitschke (BLM) & Mr. Jerry Sexton (NMOCD)

18. I hereby certify that the foregoing is true and correct

5-13-86.

SIGNED

J. J. Seeman

TITLE District Petroleum Engineer

DATE 5-13-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

Subject to
Like Approval
by State

*See Instructions on Reverse Side