

RECEIVED

Form 9-311
(May 1963)

OCT 27 1982

N. M. OIL CONS. COMMISSION

P. O. BOX 1980

HOBBBS, NM, MEXICO STATE
(Other instructions on reverse side)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYForm approved.
Budget Bureau No. 42-111424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 030187

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

-SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR Gulf Oil Corporation		3. FARM OR LEASE NAME C. E. LaMunyon	
3. ADDRESS OF OPERATOR P. O. Box 670, Hobbs, NM 88240		9. WELL NO. 30	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL & 660' FWL		10. FIELD AND TOOL, OR WILDCAT Teague Blinbry	
14. PERMIT NO.		11. SEC. T. R. M. OR BLK. AND SURVEY OR AREA Sec 22-T23S-R37E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3292' GL		12. COUNTY OR PARISH Lea	
		13. STATE NM	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

Repair Pressure

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

POH with production equipment. Set RBP at 4000', test 500#. Place 10' frac sand on RBP. Perf 940' with (4) 1/2" JH 90° phased. Establish circulation. Set cement retainer at 840', test tubing 3000#. Pump 150 sacks Class "C" with 4% gel and 50 sacks Class "C" neat. Squeeze. Reverse excess cement. Wait on cement. Drill out cement and cement retainer, test casing 500#. Wash sand off RBP and POH. Clean out if necessary. Acidize with 1000 gals 15% NEFE. RIH with production equipment.

RECEIVED

OCT 25 1982

OIL & GAS
MINERALS MGMT. SERVICE
ROSWell, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Area Engineer

DATE 10-22-82

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL IF ANY

JAMES A. GILLHAM

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

TITLE

DATE

OCT 25 1982

*See Instructions on Reverse Side

RECEIVED
OCT 29 1982
G. C. B.
HOLDS OFFICE