

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Imperial American Mgt. Co.	
3. Address of Operator P. O. Box 1005, Midland, Texas 79701	
4. Location of Well UNIT LETTER <u>I</u> <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>1930</u> FEET FROM THE <u>South</u> LINE, SECTION <u>11</u> TOWNSHIP <u>23-S</u> RANGE <u>37-E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 3251.7 GP	

7. Unit Agreement Name
8. Farm or Lease Name Lineberry
9. Well No. 1
10. Field and Pool, or Wildcat Cline-Drinkard-Aho
12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well has ceased to produce commercially. We propose to plug and abandon as follows:

1. Bridge plug and 35' cement at 6400'
2. Recover approximately 3500' 7" casing
3. Place 35 sack cement plug at stub
4. Place 35 sack cement plug at 2400-2500'
5. Place 35 sack cement plug at 1090-1190'
6. Place 35 sack cement plug at 800-900'
7. Place 10 sack cement plug top of surface
8. Fill hole with mud between plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. D. Gaudinetti TITLE Agent DATE 12-1-75

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: